

**DESCRIPTION**

Butt-Tape has two layers of 95 lb paper that is laminated using a polyurethane adhesive. The top layer of paper is pre-finished and is 2-1/16" wide and has two 7/16" diamond perforated edges. The bottom layer measures 1-3/8" wide. The tape comes in 100' and 200' rolls. Ideal for butt-joints and commercial "Top-Out" applications, Butt-Tape leaves butt-joints virtually unnoticeable. Butt-Tape requires no pre-filling, will not shrink, and does not require compound over the pre-finished laminated center.

**ADVANTAGES**

- Vertical and horizontal butt-joints.
- Commercial "Top-Out" applications.
- Ceiling butt-joints that have failed due to movement.
- Twice as fast as conventional tapes. 50% less compound. 50% less sanding. 50% faster drying time.
- No pre-filling required. No delayed shrinkage. No beading. No paint blisters.
- No compound required over laminated area of tape. Just skim coat edges.
- Two times stronger than paper tape.
- Repairs of cracked butt-joints.
- Can be applied with a Bazooka®, banjo, or by hand.

**WARRANTY**

Strait-Flex products are backed by a lifetime warranty. When applied to a sound structure, built on a permanent foundation using recommended application techniques, we warrant that these products will not edge-crack for the lifetime of the structure. Not recommended where structural movement may occur. Contact Strait-Flex International Inc for complete details.

**DIRECTIONS**

- Apply all-purpose joint compound to butt-joint with a 5" or 6" taping knife.
- Press Butt-Tape into wet compound by hand. Adjust center line of tape to center over joint.
- Wipe down edges. Immediately apply a coat of compound with an 8" or 10" taping knife to each edge of Butt-Tape. Let dry.
- Apply second coat with 10" or 12" taping knife to each edge of Butt-Tape. Let dry and sand.

**STORAGE**

Store in dry place protected from moisture.

**SUBMITTAL APPROVALS**

\_\_\_\_\_  
JOB NAME

\_\_\_\_\_  
CONTRACTOR

\_\_\_\_\_  
DATE

